



APPRENTICE PRACTICAL PROJECT 2022 INSTRUCTIONS

Please read these carefully and adhere to these instructions.

PROJECT INSTRUCTIONS

- H&S is most important at all times. If not adhered to, you will be disqualified.
- Build to BEST trade practice.
- There is NO nailing. Just screw fix everything.
- Build to the drawings and written instructions supplied and read carefully.
- All screws to be countersunk below the surface of any timber.
- Mark out everything before cutting (check twice cut once). There are NO spares.
- Accuracy is important.
- The 75mm screws are for screwing the top 90x45 to the 90x45 Rib. Screw these down from the top making sure they are 20mm into the top 90x45.
- There are 3# 75mm screws. The end screws are 230mm in from the ends and the third is in the middle.